Macroinvertebrate Sampling
Equipment & supplies needed

- D-frame dip net with 500 micron mesh net
- Metal sieve with 500 micron mesh
- Two gallon bucket
- Forceps & plastic spoon
- White dissecting tray
- Sample jars
- 99% isopropanol preservative
- 37% formalin preservative
- Write in the rain paper and clear tape for labeling